



FAQ



LA CROSSE[®]
TECHNOLOGY

WT 292



What do I do if my display is blank?

This alarm clock is equipped with a solar panel (front face of the alarm clock) which charges the rechargeable battery. It is recommended to place the alarm clock under any source of light to allow sufficient charging time for the rechargeable alkaline battery.

Make sure you have removed the protection strip which insulates the battery.

Check the polarity on your batteries to make sure they are installed according to the diagram in the battery compartment. Also make sure that you are using a quality alkaline battery. We advise against reloading batteries.



How can I set manually my time and other features of this alarm clock?

You will be able to set manually your time, if the DCF-77 signal (radio-controlled hour) is not received immediately by the alarm clock.

1. Press simultaneously the SNOOZE key (located on the top of the alarm clock) and the AL/HR key until the time is flashing.
2. Press and release the AL/HR key to set the hour and the AL/MIN key to set the minutes.
3. Press then simultaneously the SNOOZE and the AL/HR key. In the bottom left of the screen will then appear the current time zone (from -9h up to +9h) and in the bottom right will be shown the alarm snooze duration (from 1 to 59min).
4. To set time zone (from -9h up to +9h) press and release the AL/HR key.
5. Press then and release the AL/MIN key in order to set the alarm snooze duration (setting from 1 to 59 min possible).
6. When the snooze time is selected, press simultaneously the SNOOZE and the AL/HR key to confirm or wait a few seconds to automatically return to the normal mode display.