

# WT 219

## ✓ What do I do if my display is blank?

Check the polarity on your batteries to make sure they are installed according to the diagram in the battery compartment. Also make sure that you are using a quality alkaline battery. We advise against reloading batteries.

## ✓ How can I set manually my time?

You will be able to set manually your time, if the DCF-77 signal (radio-controlled hour) is not received immediately by the alarm clock.

First of all remove the batteries from the alarm clock and wait (we recommend one minute) until the display is completely blank. Proceed then as follows:

1. Insert the batteries into the compartment located on the back of the alarm clock.
2. All display segments fill in for a couple of seconds. Press DURING THIS SHORT WHILE (when all segments appear) the MODE/MIN key for a few seconds.
3. The time will now be flashing on the top line of the LCD. Press the AL/HR key in order to set the hour and MODE/MIN key to set the minutes.
4. When the correct time is selected, press the SNOOZE key to confirm or wait a few seconds. The time will stop flashing and you are done.

***NOTA:** If you are not fast enough while inserting the battery and meanwhile '0:00' is shown on the screen, you have to remove the battery and proceed again as indicated above.*

## ✓ How can I set the time zone?

*You can set the time zones ONLY after the time has been shown on the screen, either automatically thanks to DCF-77 signal (radio controlled time) or thanks to manual setting.*

1. Press MODE/MIN key for a few seconds. A number (between -9 and +9) will appear in the bottom right of the screen.
2. You can now set the appropriate time zone (from -9h up to +9h) using the MODE/MIN key.
3. Press then the SNOOZE key to confirm or wait a few seconds to automatically return to the normal mode display.

✓ **What means when "OFL" instead of data is displayed?**

"OFL" is displayed when indoor temperature data are "out of range".

NOTA:

- indoor temperature measurement range : from 0 °C to 50 °C

Correct data transmission is usually restored during the next data collection. If that is not the case, you should restart your station (see above).

✓ **How can I change the display mode?**

Press shortly the MODE/MIN key in order to have consecutively displayed:

- the indoor temperature data
- the seconds
- the alarm time
- the date (only if radio controlled time is displayed)

✓ **How can I activate alarm snooze function?**

When the alarm time is set you can activate the alarm snooze function in two different ways:

- When pressing the SNOOZE key (located under the LCD display) once during alarm sounding, the snooze function will, in the first time, be switched OFF for about 5 minutes and afterwards be activated again.
- When alarm is sounding and your "alarm clock is open" (i.e. when the flap which is used as a support is fold out) - locate the label 'SNOOZE' on the top of your alarm clock - and, while pressing, push slightly the alarm clock backwards. This impulse will activate a small black key which is dissimulated under the battery compartment. The snooze function will, in the first time, be switched OFF for about 5 minutes and afterwards be activated again.